



Creating Clarity and Scoping Profits in BIM with LOD 350


By Will Ikerd, P.E., CM-BIM, LEED AP

Clearly defined structural engineering contract scopes save engineers time, profit, and – most importantly – the personal satisfaction of their profession. Building Information Modeling (BIM) can improve this scope clarity if addressed proactively, or compound the difficulties in achieving clarity if ignored. The construction industry has reached a point where the use of BIM is not self-explanatory: it could be used to create 2D shop drawings, coordinate trades, or estimate cost. Since BIM came into existence, the industry has lacked a vocabulary for communicating the Level of Development (LOD) between parties. The BIM Forum™ *Level of Development (LOD) Specification 2015* (BIMforum.org/LOD) is an industry-changing reference that enables structural engineers to clarify their scope with BIM, providing the solution to this paramount problem of vague BIM scope definition.

Previous to this development, many model element authors were unaware of expectations upon entering a project. The LOD Specification now provides a way to define the scope of detail and input minimums for each particular component of the design. It is simply a collection of definitions describing input and information requirements and graphic/model examples of the different levels of development for building elements. The document does not outline the necessary levels of development for different steps in the construction process, leaving these determinations for each project team. Instead, it gives a common vocabulary for use between parties on a project team. It is important to note that the document is now in its 3rd edition, with the 2015 version released for public comment. Key aspects of the document are its support and input from the national BIM Masonry (BIMforMasonry.org), Steel Joist Institute (SteelJoist.org), Steel Deck Institute (SDI.org), ACI (Concrete.org), and the National Institute of Steel Detailers (NISD.org).

LOD definitions in terms of model elements* (*emphasis added*):

- **LOD 100** The Model Element may be graphically represented in the Model with a *symbol or other generic representation*, but does not satisfy



Images use with permission from BIM Forum LOD Specification & IKERD Consulting, LLC copyright 2015.

A masonry wall element progression shown from LOD 200 through 400. Copyright, BIM Forum (BIMforum.org/LOD) & IKERD Consulting (IKERD.com) 2015.

the requirements for LOD 200.

Information related to the Model Element (i.e. cost per square foot, tonnage of HVAC, etc.) can be derived from other Model Elements.

- **LOD 200** The Model Element is graphically represented within the Model as a *generic* system, object, or assembly with *approximate* quantities, size, shape, location, and orientation. Non-graphic information may also be attached to the Model Element.
- **LOD 300** The Model Element is graphically represented within the Model as a *specific* system, object or assembly in terms of quantity, size, shape, location, and orientation. Non-graphic information may also be attached to the Model Element.
- **LOD 350** The Model Element is graphically represented within the Model as a *specific* system, object, or assembly in terms of quantity, size, shape, orientation, *and interfaces with other building systems*. Non-graphic information may also be attached to the Model Element.
- **LOD 400** The Model Element is graphically represented within the Model as a *specific* system, object or assembly in terms of size, shape, location, quantity, and orientation *with detailing, fabrication, assembly, and installation information*. Non-graphic information may also be attached to the Model Element.

It is important to note that there is no LOD of an entire model; the model is a mixture of different elements within different LODs.

For permit drawings, which will be required for the foreseeable future on building projects, elements are typically only modeled to LOD 300. However, for full trade coordination, higher LOD is required, short of fabrication LOD. For this reason, the author proposed LOD 350 for bridging the gap between element development at permit drawings and fabrication level. LOD 300 does not include the information necessary for full cross trade coordination, while LOD 400 requires information that may not yet be available.

LOD 300 represents model elements traditionally shown in the plan view of a set of construction documents. This would include main structural members with information such as specific location and type. Construction Documents made from the LOD 300 model are accompanied by 2D information: general notes, typical details, specific details and specifications to define higher level information not typically shown in 1/8-inch scale plans or modeled for permit drawings. For coordination, model elements with an LOD of 350 represent information generally shown with typical details in construction drawings. This information requires trade-knowledgeable input to model accurately. Most main structural member elements are at LOD 300. However, structural engineers must be mindful that LOD 300 requires elements to be in the

correct location. For example, although the 2D plans may appear to be correct, sloping roof members that are modeled flat are not at LOD 300. Also, design-level open web bar joists at LOD 300 are not acceptable for trade coordination with MEP, as they do not have the specific manufacturer's web profiles to detect conflicts. Other areas of misunderstanding are structural elements shared with architecture, such as tilt walls, slabs and load bearing masonry walls.

A masonry wall element, for example, is shown in the progression from LOD 200 through 400 (see the accompanying graphic). Note that most structural design models would only take the wall elements to LOD 300 to create sealed 2D construction permit drawings. The wall at LOD 300 would specifically identify the masonry system, and would reference typical details and project specifications for higher levels of development details. This higher LOD information, such as but not limited to jam conditions, bond beams, grouted cells, dowel locations, and joints, would not appear until LOD 350 and higher. These higher LOD aspects would typically be modeled as part of the construction side submittal process. LOD 400 masonry modeling is currently found on more progressive BIM projects

in limited areas of building as part of virtual mockups for water proofing review at key building transition areas. Situations such as this make a compelling case for using LOD 350 as an important step between specific assemblies and detailed assemblies for coordination with manufacturer's specific content. The structural engineer's scope should address who is responsible for modeling such information at higher LOD, as owner and lead designers begin requesting higher LOD model elements.

As more projects require detailed 3D coordination, the need for accurate MEP models will become even clearer to lower the risk of the entire design team (A & E). There is little value in above ceiling coordination in taking the architectural and structural model elements to LOD 300 (specific in the actual orientation) if MEP model elements are only at LOD 200 (generic in approximate location). Structural engineers should consider adding additional services in their contracts for manual MEP coordination review if the MEP model elements are not to LOD 300. This represents the added time the structural engineer will have to invest in the project during construction administration to deal with changes in the MEP due to lack of model definition (and MEP design). For

instance, all gravity plumbing lines must slope for these elements to be at LOD 300, whereas many MEP design models do not slope these lines. This creates the risk of failing to discover that the line will not fit below the structure and above the ceiling if the lines are not modeled at LOD 300 (with slopes). The structural engineer may then be forced to consider adding web openings in their beams or redesigning shallower beams, losing time and profit.

Profit is vital in the business of any profession; structural engineering with BIM is no different. Clearly defined scopes in BIM and LOD 350 is a key to creating clarity in the design-to-construction process and aiding structural engineers in the opportunity to find profits in clearly defined project BIM scopes. ■

Will Ikerd, P.E., CM-BIM, LEED AP, is a principal at IKERD. He currently co-chairs both the Designers Forum of the AGC's national BIM Forum and the Structural Engineering Institute's national BIM Committee. Additionally, he co-chairs the AGC BIM Forum – AIA workgroup on Structural LOD. He may be contacted at info@IKERD.com.


ADVERTISEMENT - For Advertiser Information, visit www.STRUCTUREmag.org

Connect Steel to Steel without Welding or Drilling

- Full line of high-strength fasteners
- Ideal for secondary steel connections and in-plant equipment
- Easy to install or adjust on site
- Will not weaken existing steel or harm protective coatings
- Guaranteed Safe Working Loads
- Corrosion resistant




FloorFix and Grating Clip secure raised or open floors and grating.



We manufacture ICC-ES certified BoxBolt® for HSS blind connections.



FastFit universal kits for faster and easier steel connections.



For a catalog and pricing, call toll-free 1-888-724-2323 or visit www.LNAsolutions.com/BC-2