

CLT Diaphragm Design for Wind and Seismic Resistance

Using SDPWS 2021 and ASCE 7-16

By Scott Breneman, Ph.D., P.E., S.E., Eric McDonnell, P.E., Bill Tremayne, P.E., S.E., Donovan Llanes, P.E., Jonas Houston, P.E., S.E., Eric Mengzhe Gu, Ph.D., P.E., Reid Zimmerman, P.E., S.E., and Graham Montgomery, P.E., S.E.

Cross-laminated timber (CLT) has become increasingly prominent in building construction and can be seen in buildings worldwide (Figure 1). Specifically, CLT floor and roof panels have become relatively commonplace as a primary gravity force-resisting component. Now, with the availability of the 2021 *Special Design Provisions for Wind and Seismic* (SDPWS 2021) from the American Wood Council (AWC), U.S. designers have a standardized path to utilize CLT floor and roof panels as a structural diaphragm.

AWC SDPWS 2021

SDPWS 2021 is the first edition to provide direct provisions for CLT use as an element in a diaphragm or shear wall. To differentiate between CLT and light-frame lateral force-resisting systems, it adopts the terminology *sheathed wood-frame* for light-frame diaphragms (SDPWS §4.2) and shear walls (SDPWS §4.3). In addition, it includes new sections for CLT diaphragms (SDPWS §4.5) and shear walls (SDPWS §4.6). The 2021 *International Building Code* (IBC) references SDPWS 2021.

Shear Capacity

SDPWS 2021 has a single nominal shear capacity for each set of construction details, v_n , defined in §4.1.4 for use with both wind and seismic design. From this nominal shear capacity, the Allowable Stress Design (ASD) and Load and Resistance Factor Design (LRFD) wind and seismic design capacities are determined by dividing by the ASD reduction factor, Ω_D , or multiplying by a resistance factor, ϕ_D , for LRFD design, respectively, as summarized in Table 1.

CLT Diaphragms

SDPWS 2021 §4.5 contains new provisions for the design of CLT diaphragms. When using these provisions, designers use an engineered approach to meet the required design loads defined by the building code (IBC) and ASCE 7, *Minimum Design Loads and Associated Criteria for Buildings and Other Structures*.

When designing CLT diaphragms, the general requirements for all wood systems in SDPWS §4.1 apply, including limits on when wood members can be used to resist seismic forces from concrete

Table 1. SDPWS 2021 design capacity.

Loading	ASD Design Capacity $\frac{v_n}{\Omega_D}$	LRFD Design Capacity $\phi_D v_n$
Seismic	$v_n / 2.8$	$0.50 v_n$
Wind	$v_n / 2.0$	$0.80 v_n$



Figure 1. The Catalyst building in Spokane, WA (MGA|Michael Green Architecture, Katarra).

or masonry walls in §4.1.5. However, the requirements specific to sheathed wood-frame diaphragms in SDPWS §4.2 do not apply.

SDPWS §4.5.4 Item 1 requires that *diaphragm shear forces* transfer between adjoining CLT panels and between CLT panels and boundary elements through dowel-type fasteners in shear. Dowel-type fasteners include nails, wood screws, lag screws, and bolts. In practice, nails and proprietary self-tapping screws are most commonly used in CLT diaphragm connections. SDPWS §4.5.4 Item 2 does not permit the diaphragm shear connections to transfer the diaphragm tension forces, such as at chords and collectors. Figure 2, Figure 3 and Figure 4 (page 14) show examples of diaphragm shear connections.

For diaphragm shear connections, the capacities of the dowel-type fasteners (nails and screws) in shear, Z , are calculated using the yield mode equations of the *National Design Specification*® (NDS®) for Wood Construction §12.3.1. Mode III, or Mode IV is required to control the capacity of the diaphragm shear connections. An adjusted design capacity, Z^* , defined in SDPWS §4.5.4 Item 1, is the basis for the nominal diaphragm shear capacity of the connection. Z^* is similar to the adjusted design capacity, Z' , in NDS Table 11.3.1, except the ASD and LRFD-specific adjustment factors, C_D , K_F , ϕ , and λ , are not applied.

$$Z^* = Z \times C_M C_t C_g C_{\Delta} C_{eg} C_{di} C_{tn}$$

The nominal shear capacity per fastener is:

$$V_n = 4.5 Z^*$$

A regular on-center spacing, s , in inches, is often specified for fasteners in such connections. Calculating the nominal unit diaphragm shear capacity (plf) of such a connection is as follows:

$$v_n = 4.5 Z^* (12 \text{ in/ft}) / s$$

The requirements and calculation method apply to the connections transferring diaphragm shear, including panel-to-panel,

Table 2. Force increase factors for CLT diaphragm components.

Component	Force Increase Factor γ_D	
	Seismic	Wind
Chord splice connections between wood elements where the connection is using fasteners in shear controlled by yield mode III, or IV	1.5	1.0
Wood elements and connections between wood elements not meeting the above	2.0	1.5
Steel elements including connections between steel elements	2.0	2.0

panel-to-chord, and panel-to-collector connections. Figure 5 (page 14) shows an example of a CLT diaphragm with components and connections labeled for discussion. The diaphragm shear connections shown include (a) panel-to-panel connections not over framing, (b) panel-to-panel connections over a beam, (c) panel-to-collector connections, and (d) panel-to-chord connections.

The chords, collectors and their connections, (y) and (z) in Figure 5, and other structural components transferring shear, such as the CLT panels themselves, have different design requirements. These components and connections must be designed to a higher required capacity using a force increase factor applied to the diaphragm design force. The required force increase factors are found in SDPWS §4.5.4 Item 3, including Exceptions 1 and 2, and are summarized in Table 2.

The capacities of these diaphragm components are calculated using the provisions of the applicable material design method. The design capacities of wood chords, collectors, and their connections are calculated using the NDS, not the SDPWS nominal capacity (4.5 Z*) and reduction factors.

Important Detailing Considerations

CLT or Framing as Boundary Element

Boundary elements for diaphragms include chords, collectors, their splices, and their connections to the vertical lateral force-resisting system (VLFRS). Boundary elements in CLT diaphragms can include steel straps, framing components supporting the CLT such as steel or timber beams, or the CLT panels themselves. For CLT diaphragms supported by light-frame walls, the top plates of the walls below can act as chord and collector elements.

In practice, it is often advantageous to use CLT panels, coupled with top side metal straps at panel breaks, as the primary chord and collector elements. This is especially true for glulam-supported floor systems, as it can be challenging to transfer chord/collector demands across beam-to-column connections.

Connection Gaps and Tolerances

The details shown in Figure 3 and Figure 4 may be constructed with measurable gaps between the panels. These gaps may result from fabrication



Figure 2. Panel-to-panel connections with splines at The Canyons building in Portland, OR (Kaiser+Path). Courtesy of Marcus Kauffman.

tolerances and intentional under-sizing of the panels for erection tolerances. When panels meet over framing, as shown in Figure 4, and the framing functions as a shear transfer component between the panels, gaps are of little consequence to the diaphragm shear behavior. However, if CLT panels act as a boundary element and panel-to-panel bearing is used to transfer compressive axial forces, the design must account for the presence of gaps. In such cases, excessive gaps need to be filled with a non-compressible material in the boundary element region to provide an axial load path.

When using a recessed spline to transfer diaphragm shear forces between CLT panels, as seen in Figure 3, there are two types of gaps – gaps between CLT panels and gaps between the shoulders of the recess in the CLT panel and the spline placed in the recess. Under design-level loading events, CLT panels in diaphragms mostly behave as rigid elements; however, they can shift in response to applied forces, creating deformations at the panel-to-panel connections. In areas of local compression between panels, if the compression is resisted by the spline, as shown in Figure 6 (page 15), it may create a prying or buckling reaction in the spline, which may reduce the shear capacity of the spline connection.

It is recommended that, in spline connections, the gap between panels be not more than the sum of the gaps on each side of the spline to mitigate this behavior. This allows the panel gap to close and achieve bearing before the spline side member gaps close completely. To follow this recommendation, specify that the width of the recess in the CLT panels be larger than




Figure 3. Example CLT diaphragm panel-to-panel connection with a spline.




Figure 4. Example CLT diaphragm pane-to-pane connections over framing below.

the specified width of the spline material. For example, a convenient set of dimensions is a 5/8-inch-wide plywood spline with a 1/8-inch gap on each side and a nominal gap of 1/16-inch between panels.

Design Loads and Force Increase Factors

The SDPWS CLT diaphragm design method requires designing the diaphragm shear connections to the *diaphragm design forces* specified by the building code, labeled here as F_{design} . The 2021 IBC references ASCE 7-16 for the derivation of the appropriate wind and seismic diaphragm design forces and requirements. Following the SDPWS, the remaining components of the diaphragm are designed to increased diaphragm design forces, $\gamma_D F_{design}$.

A common question regarding CLT diaphragm design is how to use the SDPWS force increase factors in conjunction with various amplification factors of ASCE 7 for seismic design. For seismic design, calculate the *diaphragm design force* following ASCE 7-16 §12.10.1.1, which can be described in equation form as:

$$F_{design} = \max(F_{px}, F_x) + \Omega_0 F_{x-transfer}$$




Figure 5. Typical CLT diaphragm components and connections.

Where F_{px} is the inertial diaphragm design force calculated using ASCE 7-16 Eq. 12.10-1 through 12.10-3, F_x is the force in the diaphragm from the structural analysis of the seismic lateral force-resisting system, and $F_{x-transfer}$ is the transfer force through the diaphragm, when applicable, from one VLFRS component to another. These diaphragm transfer forces occur at out-of-plane offset irregularities of the VLFRS, such as horizontal structural irregularity Type 4 of ASCE 7-16 Table 12.3-1.

Following standard practice, as presented in the Structural Engineers Association of California's *Structural/Seismic Design Manual Vol 1*, the redundancy factor, ρ , of ASCE 7 is equal to 1.0 to determine the non-transfer design forces on the diaphragm. Therefore $\rho > 1.0$ is not included in the *diaphragm design force*, F_{design} .

Where a significant seismic diaphragm transfer force, $F_{x-transfer}$, occurs, ASCE 7-16 §12.10.1 can require applying the vertical seismic force-resisting system overstrength factor, Ω_o , to the seismic transfer forces within the *diaphragm design force*. In this case, the overstrength factor, Ω_o , is within F_{design} for the diaphragm design and thus cumulative with the SDPWS force increase factor γ_D :

$$\gamma_D F_{design} = \gamma_D \max(F_{px}, F_x) + \gamma_D \Omega_o F_{x-transfer}$$

For structures in Seismic Design Categories C through F, the required design forces for collectors potentially include amplification by Ω_o per ASCE 7-16 §12.10.2. However, if the structure is entirely braced by light-frame wood shear walls, the exception to §12.10.2 applies, and Ω_o does not apply to the collector design. Otherwise, the collector, collector splice connections, and collector connections to the VLFRS must be designed to the maximum of the three enumerated force levels

in §12.10.2 and the increased diaphragm design forces required by SDPWS 2021, shown in Table 3. As the load increase factor in SDPWS 4.5.4 Item 3 applies to the *diaphragm design forces*, the amplification of forces by Ω_o per ASCE 7-16 §12.10.2 for collector design is not cumulative with the load increase factor, γ_D , of the SDPWS. This is different than amplification of diaphragm transfer forces by Ω_o per ASCE 7-16 §12.10.1, as the transfer forces are part of the diaphragm design forces.

For structures in Seismic Design Categories D, E, and F with certain structural irregularities, the design forces for collectors and connections between the diaphragm and vertical elements may need to be increased by 25% per ASCE 7-16 §12.3.3.4. Similar to the Ω_o of §12.10.2, this is an increase in the required strength

Table 3. Design force requirements for collectors, collector splices, and connections to VLFRS.

Source of Design Force	Required Design Force*
SDPWS 2021 requirement for all collectors	
SDPWS load increase	$\gamma_D \max(F_{px}, F_x) + \gamma_D \Omega_0 F_{x,transfer}$
ASCE 7-16 §12.10.2.1 SDC C through F, when not entirely braced by wood light-frame shear walls	
7-16 12.10.2.1 Item 1	$\Omega_0 F_x + \Omega_0 F_{x,transfer}$
7-16 12.10.2.1 Item 2	$\Omega_0 F_{px,eq 12.10-1} + \Omega_0 F_{x,transfer}$
7-16 12.10.2.1 Item 3	$F_{px,eq 12.10-2} + \Omega_0 F_{x,transfer}$

*Use the maximum of applicable forces.




Figure 6. Example of inappropriate detail with a significant gap.

of specific components and not an increase in the diaphragm design force and is therefore not included in F_{design} . For collectors, collector splices, and connections to the VLFRS, γ_D is 2.0 for seismic design. Therefore, the design force, $\gamma_D F_{design}$, required by SDPWS, will always be greater than $1.25 F_{design}$ when required by ASCE 7. For the CLT diaphragm shear connections from the CLT panels directly to the collectors and VLFRS, γ_D does not apply in the SDPWS; therefore, these shear connections must be designed to $1.25 F_{design}$ if triggered in ASCE 7-16 §12.3.3.4. Figure 7 shows an example of a collector strap from a CLT diaphragm to core walls.



Figure 7. Collector strap from CLT diaphragm to core walls at Platte Fifteen building in Denver, CO (Oz Architecture/KI&A Engineers and Builders). Courtesy of JC Buck.

Diaphragm Flexibility

In ASCE 7, several specific diaphragm types can qualify prescriptively as flexible or rigid. CLT diaphragms are not included in the prescriptive categories. ASCE 7 does allow a diaphragm to be idealized as flexible when:

$$\frac{\delta_{MDD}}{\Delta_{ADVE}} > 2$$

Where δ_{MDD} is the maximum in-plane diaphragm deflection; Δ_{ADVE} is the average deflection of adjoining vertical elements of the VLFRS. ASCE 7 does not provide a method to idealize a diaphragm as rigid by analysis; however, IBC §1604.4 and SDPWS §4.1.7 address this approach. Given the large size and high in-plane stiffness of CLT panels, it is usually the case that CLT diaphragms can be idealized as rigid if used with wood structural panel shear walls or steel or concrete moment frames. When CLT diaphragms are used with concrete shear walls or steel braced frames, sometimes the diaphragms can be

idealized as rigid and sometimes as flexible. Alternative options include a semi-rigid or an envelope analysis.

Further Information

This article provides a brief summary of the new CLT diaphragm provisions in SDPWS 2021 and recommendations from the authors on their implementation. The upcoming *CLT Diaphragm Design Guide* published by WoodWorks will provide detailed information, including the design of collector and chord details, full examples, and pre-calculated tables of connection capacities. For questions and free technical support related to mass timber and light-frame wood buildings, contact the WoodWorks regional director nearest you (woodworks.org/project-assistance) or email help@woodworks.org.

Acknowledgments

Primary funding for the development of this document was provided by the U.S. Endowment for Forestry and Communities and USDA Forest Service. ■



Portions of this article were previously posted on the WoodWorks website, March 2022. It is reprinted with permission.

Scott Breneman is Senior Technical Director – Mass Timber with WoodWorks – Wood Products Council (scott.breneman@woodworks.org).

Eric McDonnell (Principal, eric.mcdonnell@holmes.us), Bill Tremayne (Principal, bill.tremayne@holmes.us), Donovan Llanes (Project Engineer, donovan.llanes@holmes.us), Jonas Houston (Principal, jonas.houston@holmes.us), and Eric Mengzhe Gu (Structural Designer, eric.gu@holmes.us) are all with Holmes.

Reid Zimmerman is the Technical Director for the Portland, Oregon office of KPFF Consulting Engineers (reid.zimmerman@kpff.com).

Graham Montgomery is Vice President and Technical Director with Timberlab (graham.montgomery@timberlab.com).